

Assembly Guide For Albany Binstore

RECOMMENDED TOOLS: HAMMER, CROSS HEAD SCREWDRIVER (BATTERY OPERATED IF AVAILABLE), STANLEY KNIFE, SAW .
ESTIMATED ASSEMBLY TIME: TWO PEOPLE 1 - 2 HOURS.
WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.

PARTS LIST	
A: 1 X BACK PANEL	E: ROOF SECTIONS
B: 1 X LEFT HAND END	F: 1 X FELT ROLL (IF FELT ROOF)
C: 1 X RIGHT HAND END	G: 1 X TRIM PACK
D: 1 X FRONT PANEL	H: 1 X NAIL & SCREW PACK

1. Decide where to position your binstore (remember to leave enough space around the building for roof overhang and maintenance). It is essential the building is assembled on a solid level base otherwise the building will not fit together properly and the door may not fit flush. Place the panels around the base - it will help you understand how they fit together.
2. Position the back panel (B) on the base. While your assistant holds the back place an end panel (C/D) on the floor to form a corner. Check that the panels are sitting flat on the floor and are butted together, fix together from the inside screwing through the end into the back using two of the screws provided.
3. Select the other end panel (C/D) and place on the floor, screw to the back as before with two screws, again making sure the sections are flat on the floor.
4. Place the front panel (E) in the remaining space and screw the front to the ends from the inside as before.
5. Place the roof section (F) on the building. Before fixing check that the roof is sitting flat with the sides, if not it is possible the floor is not level and will need packing in one corner.

SLATTED ROOF

6. Screw the hinges on the roof to the framework on the back panel.
7. Open the trim pack (H) and remove the corner strips. Fix the corner strips to each corner from the outside using two nails strip

FELTED ROOF

6. With the roof square fix to the sides by nailing through the roof into the framing on the sides & ends
7. Felt the roof using the small clout nails provided. Start by carefully removing the paper from the felt (G). Place the first strip on the low side of the roof so it overhangs the front and each side by approx 50mm. Secure at the top edge with three clout nails then pull tight and secure to the front framing every 100 – 150mm starting from the center. Place the second strip on the roof and secure at the lower edge every 100 – 150 mm then pull tight to the back and nail flush with the framing every 100 – 150mm as before. Fold the felt over the ends and secure with 2 – 3 nails.
8. Open the trim pack (H) and remove the barge boards, nail them to the sides of the roof, trim the felt if necessary. Fix the corner strips to each corner from the outside using two nails strip

We recommend you treat your building after six months and from then on annually with a recognized brand of spirit based preservative. Barretine red cedar as can be ordered from you local dealer in 5L cans
These instructions are meant as a guide only we reserve the right to alter design without prior notice.
Thank you for buying an Albany Shed.
www.albanysheds.co.uk

