

Assembly Guide For Albany Sutton & Glen

RECOMMENDED TOOLS: HAMMER, CROSS HEAD SCREWDRIVER (BATTERY OPERATED IF AVAILABLE), STANLEY KNIFE, SAW, ESTIMATED ASSEMBLY TIME: ONE PERSON 1 - 2 HOURS. WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.

PARTS LIST	
A: 1 X FLOOR SECTION	F: 1X FELT ROLL
B: 1 X PLAIN GABLE	G: 1 X TRIM PACK
C: 2 X PLAIN SIDE	H: 2 X DIAMOND FINALE
D: 1 X DOOR GABLE	I: 1 X NAIL & SCREW PACK
E: 2 X ROOF SECTIONS	

1. Lay the floor panel (A) in its desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid level base otherwise the building will not fit together properly. Place the panels around the floor - it will help you understand how they fit together.

2. Position the plain gable (B) on the back edge of the floor (the lip on the bottom overhangs the floor). Place a plain side (C) on the floor to form a corner. Check that the sides are sitting flat on the floor and the panels are butted together, screw through the gable into the side from the inside the screws provided.

3. Select the other plain side (C) and place on the floor, screw to the plain gable as before, again making sure the sections are flat on the floor.

4. Screw the door gable to the sides from the inside as before.

5. Screw the panels to the floor ensuring that you screw into a floor joist (follow the lines of nails in the floor to locate the joists).

6. Place the roof sections (F) on the building so that the overhang on one side of the roof meets at the apex, before fixing check that the roof is square and sitting flat on the sides, if not it is possible the floor is not level and will need packing in one corner.

7. Secure the two roof sections by nailing through the roof into the framing on the sides and gables.

8. Felt the roof using the small clout nails provided. Start by carefully removing the paper from the wide roll of felt, roll the felt out on a flat surface and cut in half to give two equal strips (Sutton only).

Place the first strip on the roof so it overhangs each end and approximately 50mm at the side, secure with three evenly spaced nails along the upper edge then fold the felt over the side of the roof and nail every 100 - 150 mm along the edge of the roof framing working from the middle outwards. Repeat on the other side. The Glen is usually supplied with smaller felt so roll the third strip out along the middle of the roof so the overlap is equal either side, nail down both sides every 100 - 150mm again working from the middle outwards. The Sutton has larger felt so do not require a ridge felt as the overlap on the two wide strips is sufficient, in this case nail the uppermost piece every 100 - 150mm. Fold over the ends of the felt and nail into the ends of the framing.

9. Open the trim pack and remove the four fascia boards, nail them to the ends of the roof then trim the felt if necessary. Nail on the diamond finales (its best to pre-sink the nails first on a flat surface so as not to split them).

We recommend you treat your building after 6 months and from then on annually with a recognized brand of preservative.

Barrettine red cedar can be purchased from your local dealer in 5L cans

These instructions are meant as a guide only we reserve the right to alter design without prior notice.

Thanks for buying an Albany Product. www.albanysheds.co.uk

